

1,000mm Towel Hanger Drilling Template

A1



A2



B1



B2



Important: Print this template at 100% scale (actual size).

Position the template on the wall, starting with the left-most holes. Secure the template in place.

Mark the first two holes (A1 and B1) and then the second pair (A2 and B2). [Fig. 1]

Move the template along so that the first set of holes on the template lines up with the marks you've just drawn. [Fig. 2]

Repeat the process until you have marked five sets of holes (a total of 10 holes).

- Horizontal spacing: **203 mm**
- Vertical spacing: **66 mm**

Before drilling, use a spirit level to ensure your markings are perfectly level. Use appropriate fixings for your wall type

